

USB: *basic data-transfer*

PC	idle	SYNC	SOF	Frame #	CRC5	EOP	
	11966	00000001	0xA5	0x002	0x15	**	
PC	idle	SYNC	IN	ADDR	EP	CRC5	EOP
	4	00000001	0x69	0x02	0x02	0x01	**
mouse	idle	SYNC	DATA0	data		CRC16	EOP
	5	00000001	0xC3	00 11 22 33 44 55 66 77		0xCBA8	**
PC	idle	SYNC	ACK	EOP			
	3	00000001	0xD2	**			
PC	idle	SYNC	SOF	Frame #	CRC5	EOP	
	11804	00000001	0xA5	0x003	0x0A	**	
PC	idle	SYNC	IN	ADDR	EP	CRC5	EOP
	4	00000001	0x69	0x02	0x02	0x01	**
mouse	idle	SYNC	DATA1	data		CRC16	EOP
	5	00000001	0x4B	88 99 AA BB CC DD EE FF		0x8705	**
PC	idle	SYNC	ACK	EOP			
	3	00000001	0xD2	**			